




(<https://www.weber.com/US/en/home/>)



PULSE 2000 BLK (2018) (CENTRAL EUROPE/EASTERN EUROPE) - 82010079

Pulse 2000 2018



01.18



B	66543	Hardware for lid
A	59536	Literature Kit, Pulse 1000/2000, export
B	67209	Hardware for element, Pulse
B	67132	Rubber foot, 4-pack, Pulse
1	67119	Logo for lid, Pulse '18
2	67163	Handle grip for lid, Pulse
3	67125	LH Leg assembly, Pulse '18
4	67132	Rubber foot, 4-pack, Pulse
5	67210	Grease tray rails kit
6	67209	Hardware for element, Pulse
7	67130	Mounting bracket for controller, Pulse
8	67113	Controller kit, 230v, F plug
9	67131	Knob assembly, black (qty 1)
10	67105	Lid assembly, black, Pulse '18
11	66543	Hardware for lid
12	67107	Lid liner, Pulse '18
13	67127	Set of porcelain-enameled cast iron grates, Pulse
14	67134	Element assembly, 230v, Pulse '18
15	67109	Cookbox liner, Pulse
16	67121	Cookbox/Leg assembly, Pulse 2000, black
16	67129	Cookbox, Pulse 2000, black
17	67123	RH Leg assembly, Pulse '18
18	6415	Aluminum drip pans - small (10 pack)
19	67047	Catch pan, Spirit II and Pulse
20	66693	Probe holder
20	66690	Probe w/sleeves, iGrill Mini/2
20	69332	Probe Sleeve, 4 pack, Weber Connect

JOIN OUR COMMUNITY

Sign up to receive new product news, exclusive offers, grilling tips & recipes, and more from Weber and its affiliates / subsidiaries! To learn how we use your information, see our [privacy policy](https://www.weber.com/US/en/privacypolicy.html).

[Sign up\(https://weber.com\)](https://weber.com)

*For more details on how we use your information, see our privacy policy.

COMPANY

[About Us](https://www.weber.com/US/en/aboutus.html)

<https://www.weber.com/US/en/aboutus.html>

[Newsroom](https://www.weber.com/US/en/newsroom.html)

<https://www.weber.com/US/en/newsroom.html>

CUSTOMER SUPPORT

[Support](https://www.weber.com/US/en/contactus.html)

<https://www.weber.com/US/en/contactus.html>

[Ask Us a Question](https://consumer-care.weber.com/hc/en-us/requests/new/)

<https://consumer-care.weber.com/hc/en-us/requests/new/>

REPLACEMENT PARTS

[Gas Grill Parts](https://www.weber.com/US/en/accessories/accessories-by-grill-type/gas-grill-replacement-parts/)

<https://www.weber.com/US/en/accessories/accessories-by-grill-type/gas-grill-replacement-parts/>

[by-grill-type/gas-grill-replacement-parts/](https://www.weber.com/US/en/accessories/accessories-by-grill-type/gas-grill-replacement-parts/)

[Charcoal Grill Parts](https://www.weber.com/US/en/accessories/accessories-by-grill-type/gas-grill-replacement-parts/)

EXPLORE

[eGift Card](https://www.weber.com/US/en/gift-cards/)

<https://www.weber.com/US/en/gift-cards/>

[Accessories](https://www.weber.com/US/en/shop/all-accessories/)

<https://www.weber.com/US/en/shop/all-accessories/>

